

Pillar Mount Bracket Lock Kit

Part #: 00013-2520



Included:

- A) 1/4" Drill Bit (1)
- B) 1/2" Modified Hex Bolt (1)
- C) 1/2" Cone Point Set Screws (2)

Directions:

First, make sure your gate is in the proper alignment and that your gates are swinging in the proper direction before performing the following steps.

- 1) Remove one of the pre-existing set screws from your bottom bracket.
- 2) In its place, insert the 1/2" Modified Hex Bolt.
- 3) Using a power drill insert the 1/4" Drill Bit into the 1/2" Modified Hex Bolt (***See figure 2 as an example.***) Apply pressure until drill bit has drilled through the inner tube of your operator.
- 4) Remove Drill Bit and Modified Hex Bolt from the bottom bracket and replace it with one of the Cone Point Set Screws. The point of the set screw will insert into the hole made in the inner tube and serve as a lock.
- 5) Keeping the Cone Point Set Screw in place, repeat this process for the second hole.

****Note: If you ever have to convert your gate from automatic to manual operation, simply loosen all four screws in your bottom bracket.***



Figure 2